


GREATER RAMSEY WATER DISTRICT

Standard User Meter Assembly

Installed by plumber
(Provided by Home Owner)



GRWD will provide each member a properly assembly meter but not sealed or tightened, this is done by the installer. The member is responsible for the installation of the meter assembly. A licensed plumber is recommended for the installation of the meter, but a member may install the meter.

GRWD must be contacted after the installation of the service line and meter assembly to inspect the installation. If no corrections are needed, GRWD will turn on the curb stop.

The meter must be installed in a frost free area to prevent freezing. If the meter cannot be installed inside the home, a frost proof manhole or meter pit must be supplied by the member for acceptable outside installation. GRWD must have access to the meter assembly.

GRWD shall be responsible for the normal maintenance of the meter assembly. This does not included freezing, fire or any destruction of the meter assembly.